



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

---



---

**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## MAGNETIC DIPSTICK




REF #	DESCRIPTION	QTY	BE PART #
1	MAGNETIC DIPSTICK	1	85.561.021



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## CHARGING COIL ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
1	CHARGING COIL	1	85.561.029



# PARTS BREAKDOWN GENERATOR


MODEL:BE11000

## RECOIL STARTER



REF #	DESCRIPTION	QTY	BE PART #
1	RECOIL ASSEMBLY	1	85.561.022

## ELECTRIC STARTER PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	STARTER MOTOR W/BOLTS	1	85.561.033



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## CYLINDER HEAD PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	TEMPERATURE SENSOR	1	85.561.030



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## VALVE COVER




REF #	DESCRIPTION	QTY	BE PART #
1	VALVE COVER ASSEMBLY	1	85.561.094
2	OIL STRAINER	1	85.561.096



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## SPEED ADJUSTMENT BASE PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	SPEED REGULATING SOLENOID VALVE	1	85.561.028



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## CARBURETOR ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
1	CARBURETOR ASSEMBLY	1	85.561.031






# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## AIR CLEANER




REF #	DESCRIPTION	QTY	BE PART #
1	AIR CLEANER ASSEMBLY	1	85.561.024



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## MUFFLER PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	MUFFLER AND GASKET	1	85.561.097



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## VOLTAGE REGULATOR W/BRUSHES




REF #	DESCRIPTION	QTY	BE PART #
1	AVR AND BRUSHES	1	85.561.025



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## FRAME PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	COLD WEATHER PRIMER	1	85.561.005
2	CO ALARM	1	85.561.006
3	LITHIUM BATTERY	1	85.561.032



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## WHEEL AND HANDLE SET




REF #	DESCRIPTION	QTY	BE PART #
1	WHEEL AND HANDLE SET	2	85.561.026



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## FUEL TANK ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
1	FUEL TANK COVER ASSEMBLY	1	85.561.027



# PARTS BREAKDOWN GENERATOR

MODEL:BE11000

## CONTROL PANEL



REF #	DESCRIPTION	QTY	BE PART #
1	ENGINE SWITCH	1	85.561.154
2	LED SWITCH	1	85.561.136
3	LED LIGHT	1	85.561.155
4	AC RECEPTACLE(GFCI) AC125V/20A	3	85.561.146
5	PROTECTOR 20A	3	85.561.141
6	AC RECEPTACLE AC125V250V/30A	1	85.561.145
7	PROTECTOR 30A	2	85.561.149
8	CIRCUIT BREAKER 2P-32A	1	85.561.156
9	VOLTAGE SWITCH	1	85.561.143
10	BATTERY CHARGER	1	85.561.157
11	DC12V	1	85.561.148
12	IDLE SWITCH	1	85.561.153
13	DC THERMAL PROTECTION 8A	1	85.561.147
14	ONE-CLICK START SWITCH	1	85.561.158
15	RECTIFIER BRIDGE	1	85.571.049
16	DC08	1	85.561.142
17	CHARGER MODULE	1	85.561.159
18	ONE-CLICK START MODULE	1	85.561.160

# BE

**POWER EQUIPMENT**

---

If you need technical assistance call:

**1-866-850-6662**

**(8:00am - 4:30pm PST, Mon - Fri)**