



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

---



---

**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## CRANKCASE COVER




| REF # | DESCRIPTION       | QTY | BE PART #  |
|-------|-------------------|-----|------------|
| 1     | MAGNETIC DIPSTICK | 1   | 85.561.000 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## ENGINE STARTER




| REF # | DESCRIPTION     | QTY | BE PART #  |
|-------|-----------------|-----|------------|
| 1     | RECOIL ASSEMBLY | 1   | 85.561.001 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## VALVE ASSEMBLY




| REF # | DESCRIPTION     | QTY | BE PART #  |
|-------|-----------------|-----|------------|
| 1     | VALVES ASSEMBLY | 2   | 85.561.081 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## THROTTLE SPRING SET




| REF # | DESCRIPTION                           | QTY | BE PART #  |
|-------|---------------------------------------|-----|------------|
| 1     | ROD, SPRINGS, AND THROTTLE ADJUSTMENT | 1   | 85.561.082 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## CARBURETOR ASSEMBLY




| REF # | DESCRIPTION         | QTY | BE PART #  |
|-------|---------------------|-----|------------|
| 1     | CARBURETOR ASSEMBLY | 1   | 85.561.002 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## AIR CLEANER




| REF # | DESCRIPTION          | QTY | BE PART #  |
|-------|----------------------|-----|------------|
| 1     | AIR CLEANER ASSEMBLY | 1   | 85.561.003 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## ALTERNATOR



| REF # | DESCRIPTION                    | QTY | BE PART #  |
|-------|--------------------------------|-----|------------|
| 1     | ALTERNATOR ASSEMBLY            | 1   | 85.561.083 |
| 2     | VOLTAGE REGULATOR WITH BRUSHES | 1   | 85.561.004 |
| 3     | ALTERNATOR TAIL COVER          | 1   | 85.561.084 |






# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## FUEL TANK PARTS




| REF # | DESCRIPTION                   | QTY | BE PART #  |
|-------|-------------------------------|-----|------------|
| 1     | FUEL TANK ASSEMBLY            | 1   | 85.561.012 |
| 2     | FUEL CAP W/FILTER AND SHUTOFF | 1   | 85.561.007 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE3800

## CONTROL PANEL



| REF # | DESCRIPTION              | QTY | BE PART #  |
|-------|--------------------------|-----|------------|
| 1     | ENGINE SWITCH            | 1   | 85.561.135 |
| 2     | LED SWITCH               | 1   | 85.561.136 |
| 3     | LED LIGHT                | 1   | 85.561.137 |
| 4     | AC RECEPTACLE AC125V/20A | 2   | 85.561.138 |
| 5     | CIRCUIT BREAKER 1P-25A   | 1   | 85.561.139 |
| 6     | AC RECEPTACLE AC125V/30A | 1   | 85.561.140 |
| 7     | PROTECTOR 20A            | 2   | 85.561.141 |
| 8     | DC08                     | 1   | 85.561.142 |

# BE

**POWER EQUIPMENT**

---

If you need technical assistance call:

**1-866-850-6662**

(8:00am - 4:30pm PST, Mon - Fri)